



Dedicated to Community Service

# OTAY WATER DISTRICT METER & REGISTER TYPES

Manufacturer	Model	Size	Register	Leak Indicator
Master Meter	BL062D (Bottom Load Multi-Jet)	¾" × 7.5"	3G (Analog) or Allegro (Digital)	<p><b>Analog:</b> The leak indicator is usually a small, colored triangle, star, or sweep hand near the center of the display. It moves even with very small amounts of water flow, which can signal a potential leak.</p> <p><b>Digital:</b> The leak indicator is electronic. When water flows continuously for 24 hours without stopping for at least 15 minutes, the meter shows a small water-droplet icon on the display, which may indicate a leak.</p>
Master Meter	BL072D (Bottom Load Multi-Jet)	¾" × 9"	3G (Analog) or Allegro (Digital)	
Master Meter	BL092D (Bottom Load Multi-Jet)	1" × 10.75"	3G (Analog) or Allegro (Digital)	
Badger	EBB-¾" G2 E-Series	¾" × 7.5" or ¾" × 9"	Integrated E-Series	Meters equipped with Integrated E-Series registers include a "suspected leak" indicator and a "30-day no usage" indicator. If water flows continuously for 24 hours without stopping for at least 15 minutes, or if no usage is recorded for 30 consecutive days, the meter generates an alarm message sent to the endpoint. Due to the meter's high-resolution digital measurement, small ongoing usage may also be observed by monitoring changes in the total usage display.
Badger	ECA-1" G2 E-Series	1" × 10.75"	Integrated E-Series	
Badger	M35 (Positive Displacement)	¾" × 7.5" or ¾" × 9"	HR-E LCD	Meters with HR-E LCD registers include a leak indicator. When water flows continuously for 24 hours without stopping for at least 15 minutes, the meter shows a leak symbol (often a drop or flow icon) on the display.
Badger	M55 (Positive Displacement)	1" × 10.75"	HR-E LCD	



3G - ANALOG



ALLEGRO - DIGITAL



INTEGRATED E-SERIES



HR-E LCD

Leak indicator behavior may vary by meter configuration, register type, and system settings.

For leak-detection tips, visit [otaywater.gov/how-to-check-for-leaks](https://otaywater.gov/how-to-check-for-leaks)



[otaywater.gov](https://otaywater.gov)

(619) 670-2222

2554 Sweetwater Springs Blvd., Spring Valley, CA 91978

[customerservice@otaywater.gov](mailto:customerservice@otaywater.gov)